

SIMPLE GUIDE MANUAL

1 PLUG IN YOUR *SIMPLE HOME* DEVICE

Tip: We recommend when initially setting up the device to plug it in as close to your WiFi router as possible where the signal is strongest, you can move it after setup is complete.

2 CONNECT YOUR PHONE OR TABLET TO YOUR WIFI NETWORK

Tip: Should be the same WiFi network you want to set the device up to. Check on your phone or tablet to make sure you have a strong WiFi connection in the area you are using the device. Keep Wi-Fi password on hand during setup.

3 DOWNLOAD THE FREE SIMPLE HOME APP FROM APP STORE OR GOOGLE PLAY; OPEN THE APP AND LOGIN OR CREATE A NEW USER.

4 FROM THE ALL DEVICES SCREEN; TAP THE ADD BUTTON (+) AND SCAN THE QR CODE FOR THE DEVICE.

5 VERIFY IT'S THE CORRECT NETWORK NAME; ENTER THE PASSWORD FOR YOUR WIFI NETWORK AND PRESS THE ✓.

6 EXIT THE APP AND GO TO YOUR PHONE'S WIFI SETTINGS. SELECT THE WIFI NAME BEING BROADCAST BY THE DEVICE, THEN RETURN TO THE SIMPLE HOME APP

(This step is needed for iOS and some Android devices)

Remember: Your device needs a Wi-Fi signal to operate. Don't move it outside your WiFi router's effective range. It may take a few minutes for the device to complete the connection to the WiFi network.

7 CONNECT OTHER SIMPLE HOME DEVICES.

Follow steps 4-6 to connect other devices. Your device works great with other Simple Home products. Connect them all with the same app. Do not forget to give your device a unique name and create Groups, Favorites, Actions and Schedules..

If you cannot connect your device successfully, please locate reset button and press and hold for 5 seconds.