



Wifi Window/Siren Sensor Item # XHS7-1003-WHT

# WIFI DOOR AND WINDOW SENSOR



- Magnetic sensor alerts you when a window or door is opened
- Get notified when door or window is opened with push notifications
- Can create actions with other Simple Home products to turn on magnets get separated
- Base plugs into any standard wall plug and communicates with sensors up to 10ft away
- Installs in seconds- stick sensors onto surface
- Sensor's battery last up to one year depending on usage

